

**PLEASE CHECK WEB SITE AT WWW.ONBOARDSYSTEMS.COM FOR
THE LATEST REVISION OF THIS MANUAL**

**Instructions for
Continued Airworthiness**

**Cargo Swing Suspension
System Retrofit Kit
For the
Airbus Helicopters AS350 Series Helicopter**

**System Part Number
200-286-01**

STC SR01393SE



13915 NW 3rd Court Vancouver, Washington 98685 USA
Phone: 360-546-3072 Fax: 360-546-3073 Toll Free: 800-275-0883
www.OnboardSystems.com

THIS PAGE INTENTIONALLY LEFT BLANK

Record of Revisions

<i>Revision</i>	<i>Date</i>	<i>Page(s)</i>	<i>Reason for Revision</i>
8	05/04/12	Section 5, Section 11, Section 12, Section 25 page 5, 6	Added detailed manual release cable inspection to annual/100 hour inspection. Changed 5 year/1000 hour inspection including addition of detailed part inspection criteria and moving bushing inspection to 5 year/1000 hour. Updated placards and lubrication requirements. Updated troubleshooting table.
9	05/09/14	Section 0 Page 1, Section 5 Pages 1, 2, 4, 5, 9, 10 & 14, Section 25 Pages 2-6, 8, 9, 13, 14, 18, 20 - 22	Updated Eurocopter to Airbus Helicopters. Added load cell P/N 210-249-03 and Link Assembly P/N 232-436-01. Replaced fuel drain guard P/N 290-889-00 with 290-889-01. Clarified 5 year/1000 hour inspection requirement.
10	09/11/15	Section 5 Page 10, 12, 13, 15-18, Section 25 Page 4, 20	Clarified parts requiring NDT, added inspection criteria for 235-117-00, expanded re-assembly instructions for swing frame assembly after inspection, added instructions for tightening nut for attachment of load cell assembly. Referenced 122-005-00 for storage instructions for cargo hook.
11	02/21/18	Section 4 Section 5 pages 10, 14	Updated language in section 4. Removed magnetic particle inspection requirement for load cell assembly, inserted instructions to return load cell to factory for inspection/calibration. Listed overhaul kit P/N 212-040-00 for swing suspension. Revised attach bolt diameter limit to .495" to standardize with cargo hook CMMs.
12	06/20/24	Section 5	Added disassembly and inspection of upper load cell joint to annual/100 hour inspection. Re-formatted inspection figures and inspection table.

Register Your Products for Automatic Notifications

Onboard Systems offers a free notification service via fax or email for product alerts and documentation updates. By registering your Onboard Systems products at our website, we will be able to contact you if a service bulletin is issued, or if the documentation is updated.

You can choose to receive notices on an immediate, weekly, or monthly schedule via fax, email or both methods. There is no charge for this service. Please visit our website at www.onboardsystems.com/notify.php to get started.

THIS PAGE INTENTIONALLY LEFT BLANK

List of Effective Pages

Title	Pages	Revision	Date
Cover	i, ii Blank	12	06/20/24
Record of Revisions	iii ,iv Blank	12	06/20/24
List of Effective Pages	v, vi Blank	12	06/20/24
Table of Contents	vii, viii	12	06/20/24
Section 0 Introduction	1	9	05/09/14
Section 0 Introduction	2	5	08/24/10
Section 4 Airworthiness Limitations	1, 2 Blank	11	02/21/18
Section 5 Inspection and Overhaul Schedule	1 through 17, 18 Blank	12	06/20/24
Section 11 Placards and Markings	1, 2 Blank	8	05/04/12
Section 12 Servicing	1 through 3, 4 Blank	8	05/04/12
Section 25 Operation Instructions	1	5	08/24/10
Section 25 Operation Instructions	2, 3	9	05/09/14
Section 25 Operation Instructions	4	10	09/11/15
Section 25 Operation Instructions	5, 6	9	05/09/14
Section 25 Operation Instructions	7	5	08/24/10
Section 25 Operation Instructions	8, 9	9	05/09/14
Section 25 Operation Instructions	10 through 12	5	08/24/10
Section 25 Operation Instructions	13, 14	9	05/09/14
Section 25 Operation Instructions	15 through 17	5	08/24/10
Section 25 Operation Instructions	18	9	05/09/14
Section 25 Operation Instructions	19	5	08/24/10
Section 25 Operation Instructions	20	10	09/11/15
Section 25 Operation Instructions	21, 22	9	05/09/14
Section 25 Operation Instructions	23	5	08/24/10

THIS PAGE INTENTIONALLY LEFT BLANK

CONTENTS

<i>Identification</i>	<i>Title, Page</i>
Section 0	Introduction 00-00-00
0.4	Scope, 1
0.5	Purpose, 1
0.6	Arrangement, 1
0.7	Applicability, 1
0.9	Abbreviations, 2
0.12	Precautions, 2
0.19	Distribution of Instructions for Continued Airworthiness, 2
Section 4	Airworthiness Limitations 04-00-00
4.2	No airworthiness limitations, 1
Section 5	Inspection and Overhaul Schedule 05-00-00
5.1	Cargo Hook Swing Suspension System Inspection, 1
5.2	Cargo Hook Overhaul Schedule, 17
Section 11	Placards and Markings 11-00-00
11.1	Placards, 1
Section 12	Servicing 12-00-00
12.2	Lubrication Information, 1
Section 25	Equipment and Furnishings 25-00-00
25.1	Cargo Hook Connector, 1
25.2	Description, 2
25.5	Component Weights and CGs, 4
25.12	Storage Instructions, 4
25.15	Troubleshooting, 5
25.16	Component Removal, 11
25.17	Component Re-installation, 15
25.18	General Procedures Instructions-Testing, 23
Figures	
5.1.1	Manual Release Cable Inspection, Section 5 Page 2
5.1.2	Manual Release Cable Conditions, Section 5 Page 2
5.1.3	Manual Release Cable Rigging, Section 5 Page 3
5.1.4	Load Cell Inspection, Section 5 Page 5
5.1.5	Gimbal DU Bearing Inspection Criteria, Section 5 Page 5
5.2.1	Suspension Cable to Swing Frame Attachment, Section 5 Page 8
5.2.2	Swing Frame Assembly Part, Section 5 Page 8
5.2.3	Suspension Cable Parts, Section 5 Page 9
5.2.4	Shackle Assembly Parts, Section 5 Page 9
5.2.5	Swing Frame Orientation, Section 5 Page 16

Figures continued

- 12.1 Shackle Assembly Lubrication, Section 12 Page 2
- 12.2 Upper Gimbal Grease Fitting Lubrication, Section 12 Page 3
- 25.1 Un-commanded cargo hook release, Section 25 Page 1
- 25.2 Swing Suspension System Overview, Section 25 Page 2
- 25.3 Fuel Drain Guard Overview, Section 25 Page 3
- 25.4 Fuel Drain Guard Components, Section 25 Page 4
- 25.5 Cargo Hook Electrical Connector, Section 25 Page 6
- 25.6 Wire Harness Routing, Section 25 Page 7
- 25.7 Electrical Schematic, Section 25 Page 8
- 25.8 CAL Code, Section 25 Page 10
- 25.9 Changing Dampening Level, Section 25 Page 10
- 25.10 Suspension Attachment Hardware, Section 25 Page 11
- 25.11 Manual Release Cable Connection, Section 25 Page 12
- 25.12 Manual Release Cover Removal, Section 25 Page 12
- 25.13 Load Weigh Indicator, Section 25 Page 13
- 25.14 Load Cell Hardware, Section 25 Page 13
- 25.15 Fuel Drain Guard Removal, Section 25 Page 14
- 25.16 Cable Attachment, Section 25 Page 15
- 25.17 Cargo Hook Attachment Hardware, Section 25 Page 16
- 25.18 Manual Release Cable Fitting Adjustment, Section 25 Page 17
- 25.19 Manual Release Cable Connection, Section 25 Page 18
- 25.20 Manual Release Cable Rigging, Section 25 Page 19
- 25.21 Sealant Application Location, Section 25 Page 20
- 25.22 Guard/Retainer Assembly, Section 25 Page 21
- 25.23 Lever Installation, Section 25 Page 21
- 25.24 Cable Setting, Section 25 Page 22

Tables

- 5.2.1 Swing Suspension Parts List, Section 5 Page 10
- 5.2.2 Swing Suspension Inspection Criteria, Section 5 Page 12
- 11.1 Cargo Hook Suspension System Placards, Section 11 Page 1
- 25.1 Cargo Hook Connector, Section 25 Page 1
- 25.2 Component Weights and CGs, Section 25 Page 4
- 25.3 Troubleshooting, Section 25 Page 5

Section 0

Introduction

0.4 Scope

The following information is necessary to carry out the service, maintenance, and inspection of the Cargo Hook Swing Suspension System Retrofit Kit P/N 200-286-01.

0.5 Purpose

The purpose of this Instructions for Continued Airworthiness (ICA) manual is to provide the information necessary to inspect, service, and maintain in an airworthy condition the P/N 200-286-01 Cargo Hook Swing Suspension System Retrofit Kit.

0.6 Arrangement

This manual contains instructions for the service, maintenance, inspection and operation of the Cargo Hook Swing Suspension System Retrofit Kit P/N 200-286-01 on Airbus Helicopters Model AS350 series helicopters. The manual is arranged in the general order that maintenance personnel would use to maintain and operate the Cargo Hook Swing Suspension System in service.

The arrangement is:

- Section 0 Introduction.
- Section 4 Airworthiness limitations (None apply to this system.)
- Section 5 Inspection and overhaul schedule
- Section 11 Placards and Markings
- Section 12 Servicing
- Section 25 Equipment and Furnishings

0.7 Applicability

These Instructions for Continued Airworthiness are applicable to Cargo Hook Swing Suspension System Retrofit Kits P/N 200-286-01 (with Cargo Hook P/N 528-023-01) for the Airbus Helicopters AS350 Series Helicopters. Refer to the appropriate Airbus Helicopters maintenance documentation for instructions regarding parts of the aircraft that interface with these kits.

0.9 Abbreviations

FAA Federal Aviation Administration
FAR Federal Aviation Regulation
ICA Instructions for Continued Airworthiness

0.12 Precautions

The following definitions apply to precaution flags used in this manual.



Indicates a hazardous situation which, if not avoided, will result in death or serious injury.



Indicates a hazardous situation which, if not avoided, could result in death or serious injury.



Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.



Draws the reader's attention to important or unusual information not directly related to safety.



Used to address practices not related to personal injury.

0.19 Distribution of Instructions for Continued Airworthiness

Before performing maintenance ensure that the Instructions for Continued Airworthiness (ICA) in your possession is the most recent revision. Current revision levels of all manuals are posted on Onboard Systems Int'l web site at www.onboardsystems.com. Current revision levels of all manuals are available from the factory.

Section 4

Airworthiness Limitations

4.2 No airworthiness limitations

The Airworthiness Limitations section is FAA approved and specifies inspections and other maintenance required under Secs. 43.16 and 91.403 of the Federal Aviation Regulations unless an alternative program has been FAA approved.

No airworthiness limitations are associated with this type design change.

THIS PAGE INTENTIONALLY LEFT BLANK

Section 5

Inspection and Overhaul Schedule

The scheduled inspections (Annual/100 Hour and 5 Year/1000 Hour) are defined herein. If the system is subjected to unusual circumstances, extreme environmental conditions, etc., it is the responsibility of the operator to perform the inspections more frequently to ensure proper operation. Refer to Section 5.1 for the Annual/100 Hour Inspection and Section 5.2 for the 5 Year/1000 Hour Inspection.

5.1 Annual/100 Hour Inspection

Annually or 100 hours of external load operations, whichever comes first, inspect the cargo swing suspension per the following. A grace period of 1 month or 10 hours of external load operations can be applied to this interval for maintenance scheduling convenience only. Refer also to Component Maintenance Manual (CMM) 122-005-00 for additional inspection.

NOTICE

*Hours of external load operations should be interpreted to be (1) anything is attached to the cargo hook (whether or not a useful load is being transported) and (2) the aircraft is flying. If these conditions are **NOT** met, time does **NOT** need to be tracked.*

1. Activate the electrical system and press the Cargo Release button to ensure the cargo hook electrical release system is operating correctly. With no load on it, the cargo hook must release. Reset the hook by hand after release.

CAUTION

Depressing the button continuously in excess of 20 seconds will cause the cargo hook solenoid to overheat, possibly causing permanent damage.

2. Activate the manual release system by pulling the release lever in the cockpit. With no load on it, the cargo hook must release. Reset the cargo hook by hand after release.


CAUTION

In the fully locked position the hook lock indicator must align with the lines on the manual release cover (see Figure 5.1.1).

5.1 Annual/100 Hour Inspection continued

3. Visually inspect the external manual release cable for damage and security, with emphasis on the cargo hook end of the release cable (refer to Figure 5.1.1).

Figure 5.1.1 Manual Release Cable Inspection




4. Remove the manual release cover from the cargo hook and inspect the visible section of the inner cable for kinks or frays.



Manual release cables are wearable items and must be replaced as condition requires. Broken or kinked conduit, inner cable kinks (ref Figure 5.1.2), frays, or sticky operation are each cause for immediate replacement.


Figure 5.1.2 Manual Release Cable Conditions



5.1 Annual/100 Hour Inspection continued

5. Check the manual release cable rigging. With the cargo hook load beam closed and locked, rotate the manual release lever clockwise to remove the free play (the free play is taken up when the hook lock indicator begins to move, this is also readily felt as the lever rotates relatively easily for several degrees as the free play is taken up) and hold it in this position while checking the gap between the release lever fork and the cable ball end as shown below. A minimum gap of 1/8" (3.2 mm) should be present as shown in Figure 5.1.3.

Figure 5.1.3 Manual Release Cable Rigging



6. Visually inspect for presence and security of fasteners and electrical connections.
7. Visually inspect the external electrical wire harnesses for damage, chafing and security.
8. Visually inspect for corrosion on the exterior of the cargo hook, load cell and swing suspension components.
9. Visually inspect the cargo hook and swing frame assembly bumpers for damage and security.
10. Swing the cargo hook and the swing suspension and ensure all pivot points rotate freely without binding.
11. Move the cargo hook and the swing suspension throughout their full ranges of motion and observe the manual release cable, electrical harnesses, and ground strap to ensure that they have enough slack. The release cable, harnesses, and ground strap must not be the stops that prevent the cargo hook or suspension from moving freely in all directions.


5.1 Annual/100 Hour Inspection continued

12. Visually inspect for cracks in the welded suspension frame. Pay special attention to the areas around the welds. The frame tubes contain a corrosion preventative compound, which may leak out through a crack and provide an indication. At any sign of cracking, remove and replace discrepant part.
13. Inspect suspension cables for broken strands, paying close attention to the sections around the thimbles at each end. Pass a cloth over the cables. This will clean the load ropes for a visual inspection and detect broken wires if the cloth snags on the rope. Ten randomly distributed broken wires in one rope lay (one complete rotation around the wire) or five broken wires in one strand in one rope lay is considered unacceptable. One rope lay is the length along the rope which a single strand requires to make one complete spiral around the core.
14. Disassemble and inspect the upper joint of the load cell (16) per the following, referring to Figure 5.2.2 for item numbers in parentheses ().
 - a. Remove the cotter pin (22), nut (21), washer (20), and Retaining Bushing (18) from the end of the bolt (19).
 - b. While supporting the load cell and cargo hook (28), remove the bolt and the other Retaining Bushing (18) and slide the Gimbal Shaft (17) out of the joint, separating the load cell from the Gimbal (1.1).
 - c. Visually inspect the Gimbal Shaft for signs of wear, such as pitting, galling, or reduction in diameter. If reduction in diameter is observed, refer to the criteria in Table 5.2.2. There should be no visible wear, except for light burnishing of the outside diameter surface. If the burnishing can be removed using Scotch Brite (3M P/N 7447), it is considered light.
 - d. Inspect the inside diameters of the upper lugs of the load cell (refer to Figure 5.1.4) for signs of wear such as pitting, galling, or elongation of the holes. If elongation is observed, refer to the size limits criteria in Table 5.2.2. There should be no visible wear, aside from light burnishing of the inside diameter surfaces. If the burnishing can be removed using the Scotch Brite, it is considered light.

Visually inspect for cracks around both lugs, including the transitional areas (indicated in Figure 5.1.4) where the lugs transition into the flat portion of the load cell. Inspect these areas on both sides.


5.1 Annual/100 Hour Inspection continued

Figure 5.1.4 Load Cell Inspection



- e. Inspect the flanged DU bearings (1.2) of the Gimbal (1.1) that interface with the Gimbal Shaft. As these bearings wear, the low-friction PTFE layer is removed, exposing the copper layer below (ref. Figure 5.1.5). Across the width of the bearing surface, no more than 50% should be the exposed copper layer.

Figure 5.1.5 Gimbal DU Bearing Inspection Criteria



- f. Replace worn or damaged parts. If DU bearings require replacement (refer to Section 5.2 for further disassembly instructions), press in with wet zinc chromate primer (TTP-1757 or equivalent) applied to the inside diameter of the mating hole.
- g. Re-assemble the load cell to the Gimbal per Section 25.17.

5.1 Annual/100 Hour Inspection continued

If the fuel drain guard is installed perform the following.

1. Inspect all fuel drain guard parts for corrosion, gouges, nicks, and dents. If depth of corrosion pits, gouges, nicks, or dents exceed .060", remove and replace damaged part(s).
2. Inspect Guard for damage that causes lever to bind or rub. Remove and replace Guard if it is obstructing free operation of lever.
3. Inspect for fuel leakage. If leakage is noted, re-apply sealant to Retainer as described in Section 25. Refer to Airbus Helicopters maintenance instructions for other possible causes.

5.2 5 Year/1000 Hour Inspection

Every 5 years or 1000 hours of external load operations, whichever comes first, remove the external components from the aircraft and disassemble per the following. A six-month or 100-hour grace period can be applied if needed for maintenance scheduling convenience only. No extension to maintenance is allowed beyond this tolerance grace period.

Remove the suspension by removing the quick release pins at the cable attachments to the shackle assemblies at the landing gear cross tubes and disconnecting the electrical harnesses, ground strap and manual release cable connections at the aircraft. Remove the four Shackle Assemblies from the aircraft hardpoints.

Disassemble per the following steps. For item numbers in parentheses (), refer to Figure 5.2.1 through Figure 5.2.3 for Swing Suspension parts and Figure 5.2.4 for Shackle Assembly parts. Part numbers are listed in Table 5.2.1.

1. Remove the four suspension cable assemblies from the swing frame feet by removing the cotter pin (33), nut (32), two washers (31) and bolt (29). Remove the Standoff Bushings (30).
2. Separate the Load Cell (16) and Cargo Hook (28) from the Swing Frame by removing the cotter pin (22), nut (21), washer (20), and Shaft Retaining Bushing (18) and sliding the Gimbal Shaft (17) and bolt out with the other Shaft Retaining Bushing (18).
3. At each foot of the swing frame remove the nut (7) and bolt (12) that secure the rod end fittings (13) to the swing frame feet.
4. At the upper pivoting joint of the swing frame remove the cotter pin (8) and nut (9) from the end of the bolt (10) and remove the Shaft Cap (5).
5. Slide the Swing Frame Half (3) off of the Pivot Shaft (4) and remove the bumper (6), thrust washers (15), and Gimbal Assembly (1.1, 1.2, 1.3).
6. Slide the Pivot Shaft out of the opposite Swing Frame Half (3) and remove the other Shaft Cap (5) and bolt (10).
7. Separate the Cargo Hook (28) and Hook Bumper (23) from the Load Cell by removing the cotter pin (8), nut (27), and washers (25, 26) from the end of the Attach Bolt (24) and slide the Attach Bolt out, removing the other washer (25).
8. Separate the Gimbal Assembly (34.1, 34.2, 34.3) from each suspension cable assembly by removing the cotter pin (33), nut (32), washer (31), and bolt (37).
9. Remove spiral wrap from around the frame tubes.
10. Remove bushings if it is necessary that they be replaced. All self-lubricating bushings use an interference fit to hold them in place. Use an arbor press or similar to press the bushings out of the bore they are mounted in. Do NOT use heat.

5.2 5 Year/1000 Hour Inspection continued

Figure 5.2.1 Suspension Cable to Swing Frame Attachment Hardware





Figure 5.2.2 Swing Frame Assembly Parts



5.2 5 Year/1000 Hour Inspection continued

Figure 5.2.3 Suspension Cable Parts





Figure 5.2.4 Shackle Assembly Parts



5.2 5 Year/1000 Hour Inspection continued

Table 5.2.1 Swing Suspension Parts List

Item	Part No.	Description	Qty
1*	232-143-01	Load Cell Gimbal Assembly	1
1.1	290-841-00	Gimbal	1
1.2	517-046-00	Flanged DU Bearing	2
1.3	517-056-00	DU Bearing	2
1.4***	518-003-00	Grease Fitting	1
2	235-116-00	Frame Strut Weldment	2
3	235-117-00	Swing Frame Half	2
4	290-842-00	Pivot Shaft	1
5	290-843-00	Cap-Shaft	2
6	290-862-00	Bumper	1
7	510-104-00	Nut	4
8	510-178-00	Cotter Pin	2
9	510-718-00	Nut	1
10	510-506-00	Bolt	1
11	510-510-00	Jam Nut	4
12	511-239-00	Bolt	4
13	517-055-00	Spherical Rod End	4
14	517-057-00	Flanged DU Bearing	2
15	517-058-00	Thrust Bearing	2
16	210-249-03	Load Cell	1
17	290-739-00	Shaft - Gimbal	1
18	290-740-00	Retaining Bushing - Shaft	2
19	510-443-00	Bolt	1
20	510-220-00	Washer	1
21	510-320-00	Nut	1
22	510-115-00	Cotter Pin	5
23	290-839-02	Hook Bumper	1
24	290-775-00	Long Attach Bolt	1
25	510-183-00	Washer	2
26	510-174-00	Washer	1
27	510-170-00	Nut	1
28	528-023-01	Cargo Hook	1
29	510-439-00	Bolt	4
30	290-749-00	Standoff Bushing	8
31	510-221-00	Washer	12
32	510-718-00	Nut	8
33	510-178-00	Cotter Pin	8

5.2 5 Year/1000 Hour Inspection continued

Table 5.2.1 Swing Suspension Parts List continued

Item	Part No.	Description	Qty
34*	232-142-00	Lower Attach Gimbal Assembly	4
34.1	290-746-00	Gimbal	1**
34.2	517-048-00	DU Bearing	2**
34.3	517-016-00	DU Bearing	1**
35	232-177-00	Forward Suspension Cable	2
36	232-178-00	Aft Suspension Cable	2
37	510-438-00	Bolt	4
38	290-851-00	Quick Release Pin	4
39	514-048-00	Safety Pin	4
40*	232-137-01	Shackle Assembly	4
40.1	215-396-00	Shackle Assembly Placard	1**
40.2	290-750-00	Attach Fitting Bushing	1**
40.3	290-850-00	Shackle	1**
40.4	517-016-00	DU Bearing	1**
40.5	517-047-00	Flanged DU Bearing	2**

*Item not shown assembled.

**Quantity is per assembly.

*** Not shown.

- 1) Load Cell P/N 210-249-03 supersedes P/Ns 210-249-00, 210-199-01, and 210-199-00.
- 2) Swing Frame Assembly P/N 232-145-25 is comprised of items 1 through 15.

5.2 5 Year/1000 Hour Inspection continued

Return the Load Cell Assembly (P/N 210-249-03) to the factory for inspection and calibration. The factory will inspect the condition of the load cell and perform acceptance test procedures including calibration and zero balance, repairing as necessary.

In addition, carefully inspect, and if necessary repair or replace, the detail parts in accordance with the instructions in Table 5.2.2. Inspect the parts in a clean, well-lit room.

Overhaul Kit P/N 212-040-00 is recommended to use for re-assembly of the swing suspension. The overhaul kit contains fasteners, bushings and other recommended items to be replaced. The cargo hook has its own Overhaul Kit, refer to its CMM.

Table 5.2.2 Swing Suspension Inspection Criteria

Seq	Component	Inspection Criteria & Limit	Repair Action	Finish	Recommended replacement at overhaul
1.	Gimbal (1.1), Gimbal (34.1)	Surface cracks – inspect under illuminated magnification (minimum 2X / 4 diopter).	None. Cracks of any size are cause for part replacement.	N/A	No
2.	Frame Strut Weldment (2)	Dents, gouges, and scratches – 0.020 in. (0.51 mm) deep.	Blend at 10:1 ratio as required to provide smooth transitions.	Protect affected surfaces with MIL-PRF-23377 Type 1 primer or equivalent and MIL-PRF-85285 Type 1 coating or equivalent.	No
		Surface cracks – inspect under illuminated magnification (minimum 2X / 4 diopter).	None. Cracks of any size are cause for part replacement.	N/A	
3.	Swing Frame Weldment (3)	Dents, gouges, and scratches – 0.020 in. (0.51 mm) deep.	Blend at 10:1 ratio as required to provide smooth transitions.	Protect affected surfaces with MIL-PRF-23377 Type 1 primer or equivalent and MIL-PRF-85285 Type 1 coating or equivalent.	No
		Surface cracks – inspect under illuminated magnification (minimum 2X / 4 diopter).	None. Cracks of any size are cause for part replacement.	N/A	
		Bent lateral tube, gap measured along a straight edge is greater than .35” (see figure below).	None.	N/A	

5.2 5 Year/1000 Hour Inspection continued

Table 5.2.2 Swing Suspension Inspection Criteria continued

Seq	Component	Inspection Criteria & Limit	Repair Action	Finish	Recommended replacement at overhaul
4.	Pivot Shaft (4)	Wear on outside diameter, diameter less than 0.990" (25.1 mm).	None	N/A	No
5.	Shaft Cap (5)	Dents, nicks, cracks, gouges, scratches and corrosion – 0.060 in. (1.52 mm) deep	Blend at 10:1 ratio as required to provide smooth transitions.	Passivate per AMS-QQ-P-35 or ASTM A967.	No
6.	Bumper (6)	Gouges and scratches greater than .060" deep. Splitting.	None.	N/A	No
7.	DU Bearing (1.2, 1.3, 15, 34.2, 34.3, 40.4, 40.5)	Wear – more than 50% copper showing.	None	N/A	Yes
8.	Rod End (13)	Wear on or elongation of inside diameter of spherical bearing, diameter greater than .330 in. (8.4 mm). Binding of spherical bearing in its housing.	None	N/A	No
9.	DU Thrust Washer (15)	Wear on side facing Gimbal – more than 50% copper showing.	None.	N/A	Yes
10.	Load Cell Assembly (16)	Dents, gouges, and scratches greater than .020 in. deep in the load link.	Blend at 10:1 ratio as required to provide smooth transitions.	Passivate per AMS-QQ-P-35 or ASTM A967.	No
		Elongation of or wear on inside diameter of upper lugs, diameter greater than .759 in. (19.3 mm). Galling, pitting on inside diameter.	None.	N/A	
		Dents, gouges, and scratches greater than .060 in. (1.5 mm) deep in the Covers.	Blend at 10:1 ratio as required to provide smooth transitions.	Apply conversion coating (MIL-DTL-5541) to affected Cover surfaces.	
		Wear on ID of bushing - 0.520 in. (13.2 mm)	None.	N/A	
11.	Gimbal Shaft (17)	Wear on OD - .732 in. (18.6 mm) Galling, pitting.	None	N/A	No
12.	Retaining Bushing (18)	Wear on OD - .487 in. (12.4 mm)	None	N/A	No
13.	Hook Bumper (23)	Gouges and scratches greater than .060 in (1.5 mm) deep.	None	N/A	No

Instructions for Continued Airworthiness
123-014-01

5.2 5 Year/1000 Hour Inspection continued

Table 5.2.2 Swing Suspension Inspection Criteria continued

Seq	Component	Inspection Criteria & Limit	Repair Action	Finish	Recommended replacement at overhaul
14.	Attach Bolt (24)	Wear on OD - .495 in. (12.6 mm)	None	N/A	No
15.	Suspension Cable (35, 36) Fork End Fittings	Wear on ID of clevis holes - 0.397 in. (10.1 mm)	None	N/A	No
		Dents, gouges and scratches – 0.020 in. (0.51 mm) deep	Blend at 10:1 ratio to provide smooth transitions.	Parts are 303 stainless steel, no touch up finish required.	No
		Surface cracks – inspect under illuminated magnification (minimum 2X / 4 diopter).	None	N/A	No
16.	Suspension Cable (35, 36) Wire Rope	Inspect for damage as detailed in 100 Hour/Annual Inspection	None	N/A	No
17.	Quick Release Pin (38)	Wear on OD - 0.362 in. (9.2 mm)	None	N/A	No
18.	Shackle (40.3)	Dents, gouges and scratches – 0.020 in. (0.51 mm) deep	Blend at 10:1 ratio to provide smooth transitions.	Protect affected surfaces with MIL-PRF-23377 Type 1 epoxy primer or equivalent and MIL-PRF-85285 Type 1 coating or equivalent.	No
19.	All remaining nuts, bolts, cotter pins, washers	Wear, corrosion or deterioration.	None	N/A	Yes
20.	S/N Plate	Damaged or illegible	None	N/A	No

5.2 5 Year/1000 Hour Inspection continued
Swing Frame Re-assembly

Re-assemble the suspension frame per the following.

1. Install replacement self-lubricating bushings with wet zinc chromate primer (TTP-1757 or equivalent) applied to the inside diameter of the mating bore.
2. Apply a light film of grease (Mobilgrease 28 is recommended) to the outside diameter of the Pivot Shaft (4) and insert it through one frame half, thrust washer* (15), Gimbal Assembly (1), thrust washer* (15) and through second frame half. Do not fully seat frame halves yet.


*Ensure Teflon impregnated wear surfaces (darker sides) of thrust washers are facing gimbal.
3. Rotate the Pivot Shaft so that the raised “keys” at each end are horizontal.
4. Align the rod ends (13) to seat in the pockets of the swing frame feet.
5. Before fully seating and securing the frame halves together position the bumper (6) in between them.
6. Capture each end of the Pivot Shaft with Shaft Caps (5) and insert bolt (10) through, and thread the nut (9) on. Ensure that the rod ends are aligned with the holes in both feet.
7. Torque the nut (9) to 20 ft-lbs. Rotate the nut to the next castellation, not to exceed 30 ft-lbs.
8. Install and secure cotter pin (8).
9. Secure rod ends to frame feet with bolt (12) and nut (7). Torque to 8 – 12 ft-lbs.
10. Ensure the rod ends at each end of the frame struts are parallel, i.e.- the rod ends should be able to be rotated within the limits of the pockets in the frame feet. If necessary loosen a jam nut (11), rotate the strut so the tightened rod end is against the pocket, rotate other rod end in the same direction (to be parallel), and tighten its jam nut.
11. Attach the Load Cell (16) to the Gimbal Assembly (1) per section 25.17.
12. Attach the Cargo Hook (28) and Hook Bumper (23) to the Load Cell per section 25.17.
13. Apply grease (Mobilgrease 28 is recommended) to the holes of the Fork End Fittings of the Forward and Aft Suspension Cable Assemblies (35, 36).

5.2 5 Year/1000 Hour Inspection continued

14. Assemble the Gimbal Assemblies (34) onto the Fork End Fittings of the suspension cable assemblies with bolt (37), washer (31), and nut (32).
15. Tighten nut (32) to finger tighten then rotate to next castellation if necessary to insert cotter pin. Ensure the Gimbal Assembly pivots freely on the bolt (back off to previous castellation if it does not). Install cotter pin (33).
16. Apply grease (Mobilgrease 28 is recommended) to the shank of the bolts (29).
17. Fasten the Gimbal Assemblies of the two longer Aft Suspension Cable Assemblies onto the aft feet of the Swing Frame Assembly and the two shorter Aft Suspension Cable Assemblies onto the forward feet of the Swing Frame Assembly (reference Figure 5.2.5 for orientation).

At each joint, assemble with bolt (29), washers (31), Standoff Bushings (30), and nut (32). Tighten nut to 95-110 in-lb and rotate to next castellation to insert cotter pin (33). Ensure each Gimbal rotates freely on the frame foot.

Figure 5.2.5 Swing Frame Orientation



18. Re-install the suspension system on the aircraft per Section 25.17.

5.3 Cargo Hook Overhaul Schedule

Time Between Overhaul (TBO) for the cargo hook: 5 years or 1000 hours of external load operations, whichever comes first.

NOTICE

*Hours of external load operations should be interpreted to be (1) anything is attached to the primary cargo hook (whether or not a useful load is being transported) and (2) the aircraft is flying. If these conditions are **NOT** met, time does **NOT** need to be tracked.*

Overhaul instructions for the cargo hook are contained in Component Maintenance Manual 122-005-00. Contact Onboard Systems for guidance to locate authorized overhaul facilities.

THIS PAGE INTENTIONALLY LEFT BLANK






Section 11

Placards and Markings

11.1 Placards

The 200-286-01 Cargo Hook Swing Suspension System Retrofit Kits include the following placards shown in Table 11.1.

Table 11.1 Cargo Hook Suspension System Placards

Placard part number and appearance	Location
<p>P/N 215-166-00</p>  <p>or P/N 215-168-00</p>  <p>dependent on the model of AS350 on which the system is installed.</p>	<p>Located on the belly of the aircraft near the cargo hook suspension in clear view of the ground support personnel.</p>
<p>P/N 215-271-00</p> 	<p>Located on the swing suspension frame near the serial number plate.</p>
<p>P/N 215-272-00</p> <div style="display: flex; justify-content: space-around;"> <div data-bbox="212 1591 513 1766">  <p>One Side</p> </div> <div data-bbox="548 1591 849 1766">  <p>Opposite Side</p> </div> </div>	<p>Located on the manual release cable, near the cargo hook.</p>

THIS PAGE INTENTIONALLY LEFT BLANK

Section 12

Servicing

12.2 Lubrication Information

Lubrication of the Cargo Hook Swing Suspension system is required every 500 hours of operation. To obtain maximum life under severe duty conditions such as logging or seismic work, it is recommended to lubricate the Swing Suspension every 250 hours. Recommended types of lubricants are AeroShell 17 (MIL-G-21164) or Mobilgrease 28 (MIL-G-81322).


Lubricate the Cargo Hook Swing Suspension at points noted in Figure 12.1 and 12.2.

12.2 Lubrication Information, continued

Shackle Assembly Lubrication

Remove the Shackle Assemblies from the aircraft hard points and lubricate them and the mating fittings on the suspension cables as shown in Figure 12.1. This applies to all four Shackle Assemblies on the helicopter.

Figure 12.1 Shackle Assembly Lubrication




12.2 Lubrication Information, continued

Upper Gimbal Grease Fitting

Lubricate Upper Gimbal Assembly at the grease fitting located as shown in Figure 12.2. You may have to rotate the hook slightly to access the grease fitting.

Figure 12.2 Upper Gimbal Grease Fitting Lubrication



THIS PAGE INTENTIONALLY LEFT BLANK


Section 25

Equipment and Furnishings



Un-commanded cargo hook release will happen if the manual release cable is improperly restrained. The cable must not be the stops that prevent the Cargo Hook from swinging freely in all directions. If the Cargo Hook loads cause the hook to strain against the manual release cable the swaged end of the cable may separate allowing the inner cable to activate the cargo hook manual release mechanism. The result is an un-commanded release. Ensure that no combination of collective stick or Cargo Hook position is restrained by the manual release cable.

Figure 25.1 Un-commanded Cargo Hook Release



25.1 Cargo Hook Connector

Listed below is the pin out for the cargo hook connector.

Table 25.1 Cargo Hook Connector

<i>Pin</i>	<i>Function</i>
A	Ground
B	Positive

25.2 Description

The P/N 200-286-01 Swing Retrofit Kit is a conversion kit for AS350 operators with an existing Airbus Helicopters cargo hook swing system. This kit utilizes some of the existing system's fixed components, i.e. – those which are compatible. These components include the fixed manual release cable, miscellaneous supporting brackets and miscellaneous hardware.

The Cargo Hook Swing Suspension System Retrofit Kit consists of four primary subsystems, these are the Swing Suspension Assembly, Manual Release System, Electrical Release System, and Load Weighing System.


The Swing Suspension Assembly is attached to hard points and suspended below the belly of the helicopter by its four cable assemblies. The cable assemblies are attached to a frame, which supports the cargo hook and a load cell through a gimbal (ref. Figure 25.2).

The Electrical Release System provides a means to release a cargo hook load through the use of an existing switch in the cockpit.

The Manual Release Cable System consists of a removable adapter cable that connects the cargo hook to the existing Airbus Helicopters fixed manual release cable. This system provides an additional means to release a cargo hook load.

The Load Weigh System consists of an indicator mounted within the cockpit, the load cell on the suspension, and associated wiring.

Figure 25.2 Swing Suspension System Overview




25.2 Description continued

The Fuel Drain Guard protects the fuel drain valve on AS350 helicopters from accidentally being opened. The fuel drain valve is located on the bottom of the fuel tank and extends below the belly of the helicopter. This location makes it vulnerable to damage or un-commanded fuel drainage on helicopters equipped with a cargo hook swing suspension. The most common occurrence of the cargo hook swing suspension striking the fuel drain valve happens when the helicopter lands on snow or on uneven terrain. The swing suspension has limited ground clearance and when the skid gear sinks into the snow, the swing suspension is pushed upward into the fuel drain valve, opening it and causing fuel to drain. The fuel drain valve can also be opened in flight by the swing suspension flying vertically due to aerodynamics when ferrying with no load or from recoil effects from releasing large cargo hook loads.

The Fuel Drain Guard provides mechanical protection for the fuel drain valve to prevent accidental contact while interfacing with Airbus Helicopters' existing valve, lever and control cable. The kit includes a Bracket, which replaces Airbus Helicopters' bracket and provides an optimized mounting point for the control cable.


Figure 25.3 Fuel Drain Guard Overview



25.2 Description continued

Figure 25.4 shows the components of the Fuel Drain Guard installation.

Figure 25.4 Fuel Drain Guard Components



25.5 Component Weights

The weights and cgs of the systems are listed in Table 25.2.

Table 25.2 Component Weights and CGs

Item	Weight	Station
200-286-01 Retrofit Kit		
Removable Provisions*	30.0 lbs (13.6 kg)	133 in (3375 mm)
Fixed Provisions**	4.5 lbs (2.0 kg)	110 in (2794 mm)
Fuel Drain Guard***	0.40 lbs (.18 kg)	135 in. (3430 mm)
Total	34.9 lbs (15.8 kg)	130 in (3302 mm)

* The removable provisions include the swing suspension w/ hook, external manual release cable, and external electrical release cable. These items are easily removed if they are not needed on the helicopter's mission. Refer to Suspension System Removal in Section 25.16 for removal instructions.

** The fixed provisions are those items of the kit that remain on the aircraft. These include the internal electrical wire harnesses, the load weigh indicator, fuel drain guard, and miscellaneous brackets.

*** Included with newer kits (kits shipped after August 2010).

25.12 Storage Instructions

Refer to CMM 122-005-00 for storage instructions for the Cargo Hook. Clean the exterior suspension components thoroughly of dirt and grease with a rag before packaging. Pack the unit in a heat-sealable package. If the unit is to be stored for long periods in a tropical climate it should be packed in a reliable manner to suit local conditions. Refer to MIL-PRF-23199 and MIL-STD-2073-1 for additional guidance.

Package the unit in a suitable fiberboard box and cushion the unit to prevent shifting. Seal the fiberboard box with tape and mark the box with the contents and date of packaging.

25.15 Troubleshooting

Table 25.3 is provided with the intention of isolating the cause of malfunctions within the system. Sections 25.16 and 25.17 include instructions for removing and replacing defective components. Refer to the appropriate Airbus Helicopters maintenance documentation for guidance on procedures relating to Airbus Helicopters parts that interface with this suspension system.

Table 25.3 Troubleshooting

MALFUNCTION	PROBABLE CAUSE	CORRECTIVE ACTION
Cargo hook does not operate electrically or manually.	Defective internal mechanism.	Remove and replace cargo hook (see sections 25.16 and 25.17).
Cargo hook does not operate electrically, manual cable release operates normally.	Open electrical circuit, faulty wiring, fuse, switch or solenoid.	Disconnect cable from electrical connector on cargo hook. Using multi-meter, check for 3.0 to 4.0 ohms between pins A and B of electrical connector (see note 1 below). If open indication is obtained, remove and replace cargo hook (see sections 25.16 and 25.17). Check wiring per Note 2.
Cargo hook operates electrically, but not manually.	Defective manual release cable. Defective manual release system.	Inspect manual release cable and cable connection to Cargo Hook. Remove and replace manual release adapter cable or remove and replace cargo hook (see Sections 25.16 and 25.17). Refer to Airbus Helicopters maintenance documentation for fixed section of release cable.
Load beam fails to re-latch after being reset.	Defective latch mechanism.	Remove and replace cargo hook (see sections 25.16 and 25.17).
Force required to release hook with lever on collective exceeds 14 lbs.	High cable friction or friction in internal mechanism of hook.	Remove cable from hook and check cable and hook independently (see below) to isolate problem. Refer to Airbus Helicopters maintenance documentation for fixed section of release cable.
With release cable disconnected at hook, the force required to move manual release lever on collective exceeds 6 lbs.	Kinks or wear in cable, frozen water in cable, debris or damage to cable quick disconnect fitting or lever mechanism on cyclic	Inspect individual components to isolate problem. Remove and replace defective parts (see Sections 25.16 and 25.17 for remove and replace instructions for manual release adapter cable). Refer to Airbus Helicopters maintenance documentation for fixed section of release cable.
Cargo hook manual release cable pull-off force exceeds 8 Lbs. (at the hook).	Friction in internal mechanism.	Remove and replace cargo hook (see Section 25.16 and 25.17)
Cargo hook fails to open or re-lock properly.	Defective internal mechanism.	Remove and replace cargo hook (see Sections 25.16 and 25.17).
Fuse opens when cargo hook is energized.	Short in the system, faulty wiring, fuse or solenoid.	Check for shorts to ground along length of wire harness (see note 2). Check solenoid resistance (see note 1), repair or replace defective parts.

Table 25.3 Troubleshooting continued

MALFUNCTION	PROBABLE CAUSE	CORRECTIVE ACTION
Load Weigh Indicator does not light up.	Faulty wiring or fuse.	Check the fuse (refer to Airbus Helicopters maintenance documentation) and wiring (see Note 2). If this doesn't help, remove and replace indicator per sections 25.16 and 25.17.
The displayed load on the Load Weigh Indicator is incorrect.	Incorrect calibration code.	Ensure the correct calibration code has been entered (see Note 3).
Indicator displayed load is not stable.	Dampening level is too small.	Adjust the dampening level to a larger number (see Note 4).
Indicator displayed load takes too long to change the reading when the load is changed.	Dampening level is too large.	Adjust the dampening level to a smaller number (see Note 4).
Indicator does not change with changing hook loads.	Defective load cell, indicator failure or damaged wire harness.	Check for damaged wire harness (see note 2), remove and replace wire harness assembly or load cell (see sections 25.16 and 25.17).

Notes:

1. Checking resistance at pins A and B.

Disconnect electrical release cable from cargo hook. Check for 3.0 to 4.0 ohms between pins A and B of electrical connector located on the cargo hook (see below).

Figure 25.5 Cargo Hook Electrical Connector




Table 25-3 Troubleshooting notes continued:

2. Checking Wire Harnesses.

As appropriate, before working on a circuit, e.g. - inspection, removal-installation of components, check that the aircraft system is not energized:

- "EXT. PWR. BAT." push-button is released.
- External power connector is not supplied
- Further precaution: remove the fuse(s) from the corresponding circuits (refer to Figure 25.7)

The wire harnesses are routed with and secured to existing wire bundles and are located approximately as shown below. Remove lower fairings to inspect wiring underneath the cabin floor. Inspect for general condition and chafing along length of wire runs. See Figure 25.7 for electrical wiring schematic.

Figure 25.6 Wire Harness Routing




Table 25-3 Notes continued:

2. Checking Wire Harnesses continued

The electrical schematic for the electrical release system and the load weigh system is shown below. Airbus Helicopters modification #'s 07-3450 and 07-4280 are reflected below. Earlier Airbus Helicopters configurations which affected how and where wire numbers ME1E, ME2E and ME10E of the electrical release harness and load weigh harness interface with the helicopter are shown on the following page. Refer to applicable Airbus Helicopters Wiring Diagrams Manual for additional information.

Figure 25.7 Electrical Schematic




Table 25-3 Notes continued:

2. Checking Wire Harnesses continued

Figure 25.7 Electrical Schematic, continued





Table 25-3 Notes continued:

3. Checking Load Weigh Indicator calibration code:

With the Indicator powered up and in the Run Mode, press both buttons at the same time to go to Setup. Scroll through the menu until the word CODE is displayed, then press the Right button. The display should look like this:

Figure 25.8 CAL Code




This code should match the code printed on the tag attached to the load cell cable. If this code does not match, contact Onboard Systems for further guidance.

4. Adjusting dampening level:

With the Indicator powered up and in the Run Mode, press both buttons at the same time to go to Setup. Scroll through the menu, using the Left button, until the word DAMP is displayed. To look at or change the Dampening Level press the Right button. The display should look like this:

Figure 25.9 Changing Dampening Level



The CAL and the DAMP legend is turned on and the previously set dampening level is displayed. To return to Run without changing the current dampening level press both the Right and Left buttons at the same time. To change the dampening number, use the Left button to scroll the blinking digit to the desired number. Ten dampening levels are available, from 0 through 9. At level 0 the display responds to the slightest change in weight. However, if the load bounced even slightly, the display digits would respond instantly, making the display look unstable. With a dampening level of 9, the display would be stable under the most turbulent conditions, however, it would take several seconds for the display to respond to a change in weight. The ideal dampening level will depend on the flying conditions. A mid range setting of 5 or 6 is usually adequate. After the selection has been made press both the Right and Left buttons at the same time to return to Run.

25.16 Component Removal


Cargo Hook Removal

1. Cut and remove all lockwire.
2. Remove manual release cover by removing two screws.
3. Remove the manual and electrical release cables from the Cargo Hook.
4. Remove the cotter pin (P/N 510-178-00) from the Extended Load Bolt (P/N 290-775-00). Refer to Figure 25.17.
5. Remove the castellated nut (P/N 510-170-00) from the Extended Load Bolt.
6. Remove Extended Load Bolt and all washers.
7. Remove the Cargo Hook from suspension system.
8. Remove the Hook Bumper (P/N 290-774-00) from the cargo hook.

Suspension System Removal

1. Disconnect the load cell cable at the bulkhead connector on the belly of the aircraft.
2. Disconnect the electrical release cable at the bulkhead connector on the belly of the aircraft.
3. Disconnect the ground strap at the quick disconnect near the bulkhead connector on the belly of the aircraft.
4. Disconnect the manual release cable at the quick release fitting.
5. Remove the Safety Pins (P/N 510-464-00) and Quick Release Pins (P/N 290-851-00) at the 4 joints where the suspension cable ends mate with the Shackle Assemblies (P/N 232-137-01) as illustrated below.

Figure 25.10 Suspension Attachment Hardware




25.16 Component Removal continued

Manual Release Cable Removal


1. Unclip the fwd end from the bracket on the belly of the helicopter.
2. Disengage the locking pin and unthread the Adapter Fitting.
3. Unclip the Release Cable Cap (see below) from the bracket and thread it over the open end of the fixed cable and clip it into the inboard spring clip on the bracket.

Figure 25.11 Manual Release Cable Connection



4. At the other end of the cable (at the cargo hook) remove the two screws that secure the manual release cover to the hook (see below) and unhook the cable ball end from the fork fitting.

Figure 25.12 Manual Release Cover Removal



5. Loosen the jam nut and unthread the release cable from the hook.


25.16 Component Removal continued

Load Weigh Indicator Removal

The C-39 Load Weigh Indicator is located on the RH forward door pillar.

1. Disconnect electrical connector from the back of indicator.
2. Remove the four screws (P/N 510-457-00) that secure the indicator to the mounting bracket and remove the indicator.


Figure 25.13 Load Weigh Indicator



Load Cell Removal

1. Disconnect the electrical connector on the belly of the helicopter.
2. Remove the Cargo Hook per the above instructions.
3. Remove the Load Cell Assembly from the gimbal on the suspension frame (not shown) by removing the hardware as illustrated below.

Figure 25.14 Load Cell Hardware




25.16 Component Removal continued

Fuel Drain Guard Removal

1. Drain fuel tank.
2. Remove cotter pins from Guard.
3. Remove lever.
4. Remove safety wire between fuel tank valve and retainer tab.
5. Remove ground strap from Retainer.
6. Unthread fuel drain valve from tank and remove it and washer.
7. Remove Guard and Retainer.
8. Remove Bracket.

Figure 25.15 Fuel Drain Guard Removal



Self Lubricated Bushing Removal

All self-lubricated bushings use an interference fit to hold them in place. Use an arbor press or similar to press the bushings out of bore they are mounted in.




Do not use heat on any of the parts when removing the self-lubricated bushings. These parts are all heat-treated and using heat may affect their mechanical properties.

25.17 Component Re-installation

Suspension Re-installation

1. Inspect the Suspension for evidence of damage, corrosion, cable fraying, freedom of rotation at all pivot points, and security of fasteners. If damage is evident, do not use the items until they are repaired.
2. Verify that the part number of the cargo hook removed matches one of the numbers on the list in the Applicability section of this manual. If it does not, do not attempt to use the cargo hook, contact the factory for clarification
3. Install the Suspension by securing the four suspension cable ends to the shackles with the quick release pins. Note: Install the Suspension such that the longer cables attach to the rear attach points and are pinned to the inboard holes of the Shackle Assemblies (as illustrated below).
4. Connect the load cell cable connector at the bulkhead connector at the belly of the aircraft.
5. Connect the ground strap attached to the cargo hook to the ground strap connection at the belly of the aircraft.
6. Connect the electrical release cable at the bulkhead connector at the belly of the aircraft.
7. Connect the manual release cable at the quick release fitting.

Figure 25.16 Cable Attachment




25.17 Component Re-installation continued

Cargo Hook Re-installation

1. Inspect the Cargo Hook for evidence of damage, corrosion and security of lock wire and fasteners. If damage is evident, do not use the items until they are repaired.
2. Inspect the suspension system to ensure that all components are in serviceable condition before re-installing the cargo hook to the suspension system.
3. Attach the Cargo Hook, P/N 528-023-01 to the suspension system by installing the Bumper P/N 290-774-00 over the Cargo Hook.
4. Install the load bolt P/N 290-775-00 and washer P/N 510-183-00 as illustrated in Figure 25.17.
5. Install washer P/N 510-183-00 and washer P/N 510-174-00 over bolt end.
6. Tighten nut P/N 510-170-00 on bolt to finger tight until seated, then rotate nut to previous castellation (if necessary) to install and secure cotter pin P/N 510-178-00.

Figure 25.17 Cargo Hook Attachment Hardware



NOTICE

The cargo hook load beam must point to the left side of the helicopter when looking from the rear (as shown above).

25.17 Component Re-installation continued


Manual Release Cable Re-installation

Connect the removable manual release cable (P/N 268-024-02) to the cargo hook first, per the following instructions:

Remove the manual release cover from the cargo hook. Thread the fitting at the end of the manual release cable into the manual release boss on the hook side plate until the threads protrude approximately .125" inch beyond the boss and secure with jam nut (as shown in Figure 25.18).

Leave the cover off of the cargo hook until the other end of the release cable is connected, in order to verify proper setting.

Figure 25.18 Manual Release Cable Fitting Adjustment



25.17 Component Re-installation continued


Manual Release Cable Re-installation continued

Connect the other end of the removable cable assembly to the end of the fixed cable by sliding the Adapter Fitting back to expose the Handshake Fitting and connecting this fitting to the Handshake Fitting on the fixed cable as shown below.

Thread the Adapter Fitting on the removable cable onto the fixed cable adapter fitting and lock in position by engaging a castellation with the Locking Pin.

Snap the removable cable Adapter Fitting into the inboard spring clip on the bracket on the lower rear RH fairing.

Figure 25.19 Manual Release Cable Connection



25.17 Component Re-installation continued

Manual Release Cable Re-installation continued


Verify proper setting at the hook:



The cargo hook must be closed and locked (see below) when verifying and adjusting the manual release system.

Place the cable ball end fitting into the hook manual release fork fitting as illustrated in Figure 25.20. Move the manual release lever in the clockwise direction until it is against the cam stop. Measure the cable ball end free play with the manual release handle in the cockpit in the non-release position. The gap must measure a minimum of .125" (3.2 mm) (see below).

Figure 25.20 Manual Release Cable Rigging



If the gap does not measure at least .125", make adjustments at the hook only. This is done by disconnecting the cable at the interface with the fixed manual release cable (Figure 25.19), loosening the jam nut, and rotating the cable in the required direction.

25.17 Component Re-installation continued

Load Weigh Indicator Re-installation

1. Place the Load Weigh Indicator into the mounting bracket on the RH door pillar and secure with four screws (P/N 510-457-00).
2. Connect the electrical connector on the wiring harness to the connector on the back of the indicator.

Load Cell Re-installation

1. Attach the load cell assembly to the gimbal fitting on the suspension frame with hardware as illustrated in Figure 25.14.
2. Tighten nut to 60-70 in-lbs and rotate to next castellation if necessary to insert cotter pin.

CAUTION

The Load Cell Assembly must pivot freely about its upper attach point independently of the bolt (P/N 510-443-00) and nut, back the nut off to previous castellation if necessary to achieve this.

3. Connect the load cell electrical cable connector on the load cell cable to the connector on the belly of the helicopter.


Self-Lubricated Bushing Re-installation

1. Install bushings with wet zinc chromate primer on the outside diameter.
2. Use an arbor press and an appropriately sized press tool to push the bushing into the hole until it is fully seated.

Fuel Drain Guard Re-installation

1. Remove residual sealant from the tank and Retainer, P/N 290-888-00, taking care not to mar the sealing surfaces. Prepare the areas for sealing per Airbus Helicopters Standard Practices Manual.
2. Prepare PR1422-B or equivalent sealant per Airbus Helicopters Standard Practices Manual. Apply sealant to Retainer.

Figure 25.21 Sealant Application Location




3. Place the Retainer (P/N 290-888-00) inside the Guard (P/N 290-889-01), by inserting the tab through the slot. See Figure 25.22.

25.17 Component Re-installation continued


Fuel Drain guard Re-installation continued

Figure 25.22 Guard/Retainer Assembly



4. Place these two items onto the boss on the bottom of fuel tank, aligning the notch in the Guard with the key on the bottom of the fuel tank.
5. Secure the Guard and Retainer by re-installing the Fuel Drain Valve with new Fuel Valve Seal, 610-024-00. Use a flat-blade screwdriver to prevent the Retainer from twisting when tightening the Fuel Drain Valve. Torque per Airbus Helicopters specifications.
6. Secure the Fuel Drain Valve with safety wire using the small hole in the retainer tab.
7. Re-install the electrical connections to the Retainer tab per Airbus Helicopters Electrical Bonding Procedure. Refer to Airbus Helicopters Standard Practices Manual, 20.02.07.
8. Install the Lever by placing it in Retainer slot and rotating upwards. Secure with cotter pin (P/N 510-526-00). See Figure 25.23.

Figure 25.23 Lever Installation



25.17 Component Re-installation continued

Fuel Drain Guard Re-installation continued


9. Install a second cotter pin through the other holes in the Guard (this cotter pin is for valve protection only and is not used for rigging purposes).
10. Prepare to install Bracket (P/N 290-893-00) by threading the control cable through the Bracket hole. Install Bracket using the two screws removed previously.
11. Pass the cable through the Spring (Airbus Helicopters P/N 350A55-1044-21) and Lever (Airbus Helicopters P/N 350A55-1043-21). Slide the Sleeve (Airbus Helicopters P/N N1-5ALU) over the cable and secure with Cable Grip (Airbus Helicopters P/N 58-2-009).



To avoid inadvertent fuel loss, Airbus Helicopters P/N 58-2-009 Cable Grip must be used with this installation.

12. Adjust the cable travel by doing the following: allow the lever to rest against the cotter pin stop. Slide the Cable Grip up to the bottom of the lever and secure (see Figure 25.24). Trim excess cable to within .25" of cable grip.

Figure 25.24 Cable Setting



13. Allow the sealant to cure per Airbus Helicopters Standard Practices Manual before adding fuel. Verify proper cure of unused sealant.
14. Refill fuel tank and check for leaks.

25.18 General Procedural Instructions-Testing

After re-installation of the cargo hook, perform the following:

1. Activate the electrical system and press the Cargo Hook release button to ensure the cargo hook electrical release is operating correctly. The mechanism should operate smoothly and the Cargo Hook must release. Reset the hook by hand after the release. If the hook does not release or re-latch, do not use the unit until the difficulty is resolved.

CAUTION

The cargo hook release solenoid is intended to be energized only intermittently. Depressing the electrical release button continuously in excess of 20 seconds will cause the release solenoid to overheat, possibly causing permanent damage.

2. Activate the release handle located on the collective to test the cargo hook manual release mechanism. The mechanism should operate smoothly and the Cargo Hook must release. Reset the hook by hand after release. If the hook does not release or re-latch do not use the unit until the difficulty is resolved.
3. Swing the installed Cargo Hook and the suspension to ensure that the manual release cable assembly and the electrical release cable have enough slack to allow full swing of each component without straining or damaging the cables. The cables must not be the stops that prevent the Cargo Hook or the suspension from swinging freely in all directions.
4. Visually check for presence and security of fasteners, and condition of cables. Swing the Cargo Hook and the suspension in fore and aft and side to side directions to check for freedom of rotation at all joints.